



Note 1: Membrane must be fastened around the perimeter of the drain with the same fastening pattern as the field membrane, no less than 1 fastener per drain.

Note 2: The openings in the CDRs must face in opposite directions. Sealant must be behind the membrane at the CDRs' location.

Note 3: Dome Strainer attachment tabs are secured to the roof membrane by heat welding.

Note 4: Duro-Last Dome Strainers (optional) must only be used with roof drains that are 6 inches in diameter or less.

Note 5: All field welds shall be a minimum of 1-1/2 inches wide.

Note 6: Refer to specifications for vapor barrier, insulation and cover board requirements.

REVISED: 07/17/2017	DRAINAGE DETAIL FOR MECHANICALLY FASTENED SYSTEMS
PREVIOUS: 01/31/2017	ROOF DRAIN WITH DOME STRAINER
SCALE: NONE	NEW CONSTRUCTION OR RE-ROOF