



- Note 1: Tabs that are parallel to the expansion joint must be mechanically fastened with the same fastening pattern used on the membrane in the field area.
- Note 2: Leave the membrane covering the expansion joint loose enough to allow for movement of the building on either side of the joint.
- Note 3: All field welds shall be a minimum of 1-1/2 inches wide.
- Note 4: Refer to specifications for vapor barrier, insulation and cover board requirements.

REVISED: 01/31/2017	GENERAL DETAIL FOR MECHANICALLY FASTENED SYSTEMS
PREVIOUS: 01/01/2009	CURB-STYLE EXPANSION JOINT
SCALE: NONE	NEW CONSTRUCTION OR RE-ROOF