



INSTRUCTIONS

1. Install coping cleat per Detail Drawings 6050 or 6052.
2. Install splice plate centered on coping joint. Install approved Duro-Last sealant along both long top edges of splice plate.
3. Install coping cap over top of splice plate. Leave a 1/4-inch gap between sections of coping to allow for expansion and contraction.

Note: All joining surfaces such as joints, splices, corners, and end caps must have an approved Duro-Last sealant applied to them.

REVISED: 06/16/2017	PARAPET WALL DETAIL FOR MECHANICALLY FASTENED SYSTEMS
PREVIOUS: 02/02/2017	COPING CAP SPLICE PLATE INSTALLATION
SCALE: NONE	NEW CONSTRUCTION OR RE-ROOF