



Note 1: This detail applies to roll good membrane installations.

Note 2: Install fasteners so edge of plate is flush with edge of membrane.

Note 3: End of roll fastening should be same as lap fastening as per respective zone (field, perimeter, corner).

Note 4: Position next roll so that it overlaps end of installed roll a minimum of 6 inches. Duro-Last EV, Duro-Tuff® and Duro-Fleece® are all premarked with lap lines set 6 inches from edge of membrane.

Note 5: Install patches at T-Laps per Detail Drawing RG1066.

REVISED: 02/03/2017	GENERAL DETAIL FOR ROLL GOOD MECHANICALLY FASTENED SYSTEMS
PREVIOUS: 04/03/2014	END-LAP FASTENING AND OVERLAP
SCALE: NONE	NEW CONSTRUCTION OR RE-ROOF