



INSTRUCTIONS

1. Precut a 14 x 10-inch opening in upper third of parapet wall a minimum of 8 inches from finished roof surface.
2. Install Duro-Last parapet flashing according to Detail Drawing 6010.
3. Cut parapet flashing to size of precut opening and backseal with approved Duro-Last sealant (see side profile).
4. Install Duro-Last Parapet Wall Vent over opening and fasten metal flanges with pre-punched holes (minimum of 2 per side).
5. Weld entire perimeter of 6-inch skirt with a minimum of a 1-1/2-inch field weld to the parapet flashing.

REVISED: 02/02/2017

VENT DETAIL FOR MECHANICALLY FASTENED SYSTEMS

PREVIOUS: 04/01/2010

PARAPET WALL VENT

SCALE: NONE

NEW CONSTRUCTION OR RE-ROOF